



**Tool - Lift / 600-1**

**Parts list ErgoStrap 600/600E**  
**Tool-Lift**

<b>Item</b>	<b>Quantity</b>	<b>Unit</b>	<b>Designation</b>	<b>Art. No.</b>
5.1.1	1	ea.	Holder for Tool-lift	300001
5.1.2	6	ea.	Hexagonal recessed screw	191001
5.1.3	6	ea.	Hexagonal nut	191002
5.1.4	12	ea.	Washer	191003
5.1.5	1	ea.	Buffer block	600151
5.1.6	2	ea.	Recessed screw	191004
5.1.7	2	ea.	Hexagonal nut	191005
5.1.8	1	ea.	Sliding disk	300024
5.2.1	1	ea.	Holder - linear guide	300006
5.2.2	2	ea.	Cup spring	300012
5.2.3	1	ea.	Washer	191006
5.2.4	1	ea.	Hexagonal nut with clamp	191007
5.2.5	2	ea.	Conical roller, concentric, with ball bearings	300020
5.2.6	2	ea.	Conical roller, eccentric, with ball bearings	300021
5.2.7	4	ea.	Hexagonal nut	590019
5.2.8	1	ea.	Compressed air spring for linear guide	300015
5.2.9	2	ea.	Hexagonal nut	590019
5.3.1	1	ea.	Linear guide	300019
5.3.2	1	ea.	Cover	300009
5.3.3	1	ea.	Left stop	300007
5.3.4	1	ea.	Right stop	300008
5.3.5	2	ea.	Rubber-metal buffer	300017
5.3.6	2	ea.	Washer	191003
5.3.7	4	ea.	Hexagonal recessed screw	191010
5.4.1	1	ea.	Holder, swivel unit, fixed side	300002
5.4.2	2	ea.	Recessed screw	191011
5.4.3	1	ea.	Hexagonal nut	191002
5.4.4	2	ea.	Plain bearing	300010
5.4.5	1	ea.	Washer	191012
5.4.6	1	ea.	Hexagonal nut with clamp	191013
5.5.1	1	ea.	Holder, swivel, loose side	300003
5.5.2	1	ea.	Compressed air spring for locking tool	300022
5.5.3	2	ea.	Hexagonal nut	590019
5.5.4	2	ea.	Clips bearing	300011
5.5.5	1	ea.	Tension spring, swivel unit, Tool-Lift	300016
5.5.6	1	ea.	Take- up, locking tool	300004
5.5.7	1	ea.	Hexagonal recessed screw	191014
5.5.8	2	ea.	Plain bearing	600110
5.5.9	1	ea.	Hexagonal nut with clamp	590011
5.5.10	1	ea.	Locking bolt	300013
5.5.11	1	ea.	Hexagonal nut	191016
5.6.1	1	ea.	Holder, locking tool	300005
5.6.2	2	ea.	Hexagonal recessed screw	191017